

G S M G A T E

Blue Gate A *Brave UMTS*



Installation guide V 2.0

Basic features:

Blue Gate A Brave UMTS is quad band GSM Gate based on Cinterion PH8 equipped by a lot of adjustable features increased comfort of service. It has been designed for GSM network 800/850/1900MHz and 2100MHz UMTS.


- Polarity reversal of telephone line allows exact detection of start and end of call.
- CLIP FSK Bell
- Call billing allows control exact call duration due tax pulses 12/16 kHz (1. pulse when outgoing call is picked up).
- Beeps in minute period into the call allows easy identification of GSM call.
- Monitoring system allows sending SMS to preprogrammed number when voltage of Back up batteries drops, unit is logged to GSM network, no picks up number of ringing called person/connected device doesn't react for ringing) etc.
- USB 2.0 full speed interface - simultaneous voice and data connections in UMTS network
- Direct Call (Baby Call) - Automatic dialing the number stored on the SIM

Options:

- Option USB port with PC software allows you easy configuration as same as sending and receiving SMS messages (via SMS mail sw)* or data transmission.
- You can add a backup battery for up to 10 h of operation at power failure.

Thanks of many BlueGate features you can satisfy very wide group of customers. By setting of permitted numbers to memory of BlueGate you can restrict unrequested calls (to public numbers).As same as you can set BlueGate to provides incoming calls only.

INSTALLATION



Insert the SIM card up the picture and by press fix it in operation position. **Before inserting the SIM card we recommend checking at various mobile phone state of the SIM card (logging with or without PIN, PIN, etc.) and set logging without PIN. When you want logging with PIN you have to preprogrammed this PIN and set logging with PIN (via table of programming). Without this setting the Gate wont work. DO NOT FORGET ANTENNA CONNECTION!** The available place for installation select up following point of view:

1. distance from PBX – possibility of GSM interferences to other PBX lines as same as lenght of line from Gate to PBX (max. 200m)
2. main 230 V for power supply of Gate
3. Quality of GSM signal at the installation place of GSM Gate

Quality of GSM signal

The sound quality depends on BTS setting where you are connected by the Gate. To find best place for antenna mounting you can use either mobile phone or yellow LED flashing on front of unit (via. Table at the end of manual). The suitable signal power is 3 scales of mobile graduation.

To check and find best position from GSM signal point of view you can use also GG SET (configuration sw). More in manual for GG SET.

Connection of antenna

When you connect magnetic antenna keep on mounting at bigger iron subject. This subject makes „against-weight“ at its depends the power of radiated signal

When you inserted SIM card as same as all cables are connected (**do not forget that Blue gate is connected on external line not on extension**) connect device to main 230V. Blue LED “feeding” lights up (via LED table) and starts flashing yellow GSM LED in rhythm of busy tone. After cca 30 seconds the yellow LED start flashing up GSM signal strength (via LED table).When pick up connected analogue phone or call to BlueGate from PBX the LED of analogue line lights up (green LED). In the phone is hearing dial tone of BlueGate. It is ready to use.

The most often problems during Blue Gate compact installation:

- All LED is not lighting.Problem in power supply. Check connection to main 230V as same as connection of adapter to BlueGate.
- The LED “power supply” lights. When you make connection to Gate green LED is ON and in handset you hear busy tone. Yellow LED flashing in period „GSM modul doesnt communicate with CPU“. During work with USB could be programmed fix communication rate for GSM modul. Use USB to programm rate on „autobauding“.
- The yellow LED flashing in period „PIN unreadable“. After calling to BlueGate you get busy tone. The SIM

card requires PIN, which is not preprogrammed or is preprogrammed wrongly.

- The LED „communication to GSM,, is flash shortly one for 2 sec. After calling to BlueGate you are hearing busy tone. BlueGate is not log into GSM network – bad signal.
- The yellow LED „communication to GSM,, is flashing up signal strength“. After calling to BlueGate is not light up green LED is not light up and in analogue phone is quiet. It interrupted conduction of analogue line or so much big resistance in current loop (for example:(longer cabel between PBX and BlueGate).
- The yellow LED „communication to GSM,, is flashing up signal strength“ as same as green LED lights up. The PBX hold „pick up“ line of GSM Gate. By incoming call you can remove this issue. In other cases check PBX manual.
- The BlueGate works but call is disturbed by interference. Incorrect position of antenna against telephone line. Change antenna position.

Note:

Default you make by parametr 99 in programming mode (via programming table at page 11).

Alle LEDs flashing as same as tone types are mentioned in tables at the end of manual.

USB

A Brave BlueGate UMTS can have up to 2 independent USB ports.

1) Built-in USB port is independent of the other activities of the gate and is intended primarily for use as a USB UMTS modem for data transmission, the Internet or for SMS messages. Description and working with this port is described in a separate manual.

2) You can purchase USB tool for PC configuration of the unit. It is optional. This tool is connected via 6 wire cable to the units in middle of phone line. (via picture on page 2). You can control GSM modul directly via virtual COM port. This port is intended primarily for setting the parameters of the gate via GGset program. It can also be used for sending SMS, checking gateway activities (eg, record CLIP and times of incoming calls, signal strength...), etc.

When unit is working via this USB port, then is busy for voice connection. When you pick up the line you will hear busy tone. The unit is monitoring data transmission by this port. The data transmission can not be permanent therefore the unit stays in data mode 10 seconds after finishing of data transmission. Then is going back to Voice mode (calling). The same is when you are calling over unit. It is busy for data transmission.

The optional sw supply to unit for sending and receiving SMS messages is SMS mail. It is working under Outlook, Outlook Expres, Opera etc. And you can work with SMS as with normal e mails. (see manual for SMS mail).

CONFIGURATION

The programming mode is set after acknowledgement dialing to Blue Gate. In the analogue phone is waiting tone. After password inserting is tone changing to programming tone. Then you can programming each features of Blue Gate (via table of programming)

Progress of programming:

- ① Dial 2 digits number of programming feature.
- ② Dial 1 to 4 digits number for feature value programming.
- ③ Wait for a tone of confirming request (3 short tones).
- ④ Confirm the feature by dialling acknowledgement (#)
- ⑤ Wait for confirming tone.
- ⑥ Follow programming tone again.
- ⑦ Finish programming by hang up a phone.

Example: programming of new permitted fix numbers (02) to memory 09:

Dial acknowledgement (default is #). In phone you are hearing waiting tone (■—■—■—■—). Dial password (default 0000). Waiting tone is changing to programming tone (■—■—■—■—). Dial 1902. Wait for tone of confirming request (3 short tones). Confirm the feature by dialling acknowledgement (#). Wait for confirming tone (one long tone). Finish programming mode by hang up a phone.

Warning: After dialling of parametr value you have to wait for 3 short tones and then dial acknowledgement # . Wait for long tone confirm acceptation of this parametr .

Notes to each parametres:

11 - 19 When you programm some prefixes the BlueGate A Bravellows outgoing calls starts by those prefixes only. The others will get busy tone. When memories will be empty the calling wont be restricted (default). Memory of prefixes can content 1 digit only. If you insert 1 digit only the BlueGate will check first position only.

Rewriting of memory – by storing of new fix-numbers are old fix-numbers erased.

Erasing of memory - Memory you will erase by storing of „nothing“. You dial only number of memory which you want erase, wait for confirm tone and confirm it.


22 very important feature is acknowledge character setting. Default is #. When is # used for PBX features you can change it on *.


32,35 The GSM phones requested command to connection on inserted number. The BLUE GATE will send a command immediatly after acknowledge character dialling (#).


33 **Direct Call** - When the value is 01 (the shortest waiting time to dialing) is activated "Direct Call" (Baby Call). After picking up is no need to dial a phone number. Is automatically dialed phone number stored on the SIM card under the name DCALL. Store the number on the SIM either by directly writing after inserting the SIM card into any mobile phone or by software GGset (folder "Phone Book")

37 This parameter can be entered (if necessary) immediatly after switching gates (Go into the programming mode in the busy tone - see note. 3 below). Without setting, in some cases, may not be available SIM card (PIN).

Notes:

-  Changes are valid after hang up only (finishing of programming mode). It is very important especially in acknowledge character changes- till hang up you must use previous acknowledgement.

-  **After numbers dialing you must wait for confirming request , insert acknowledge character and wait for confirming tone. When you insert acknowledge charater before wont be accepted.**

-  Switch to programming mode is possible even in busy tone.











-  Some parametres are possible to programm by PC only

Table of programming














Dial number					Feature	Default			
0	0	n	n	n	Password nnnn to programming mode access	0	0	0	0
1	1	n	n	n	Memory x for permitted fix number (1 to 4 digits)				
1	2	n	n	n					
1	3	n	n	n					
1	4	n	n	n					
1	5	n	n	n					
1	6	n	n	n					
1	7	n	n	n					
1	8	n	n	n					
1	9	n	n	n					
2	1	n			Reversal polarity n=0 OFF n=1 ON	0			
2	2	n			Acknowledge character setting n=0 - # n=1 - *	0			
2	3	n			Type of dial tone n n=0 – permanent tone n=1 – dial tone up table of tones n=2 - dial tone of public lines operator n=3 - quiet	0			
2	5	n			Signalization to the call – short tone each minute n=0 – tone is turn off n=1 – tone is turn on	0			
2	6	n			Restriction of call duration n=0 – without restriction n=1 – call duration restricted at 10 minutes	0			
2	8	n			outgoing DTMF INBAND/OUTBAND n = 0 – INBAND DTMF n = 1 – OUTBAND DTMF	0			
3	2	n	n		Waiting for last number nn sec. (01 to 15) (after finishing of dial by acknowledge character is sending immediatly)	0	6		
3	3	n	n		Waiting nn sec. for dial after pick up (00 to 99 sec) („00„ waiting is not limited) („01“ Direct Call)	0	0		
3	5	n	n		Number of dialled numeral, after its is dial send immediatly (lenght of telephone number) nn=00 – function none active nn=01-19 – number of numeral telephone number	0	0		
3	7	n	n	n	Storing of PIN	1	2	3	4
3	8	n			Amplification of sound in outgoing direction (1 to 4)	1			
3	9	n			CLIR feature, switching OFF outgoing CLIP (#31#) n=0 OFF n=1 ON	0			

7	1	x	x	y	y	Xx= 00 No charging pulses Xx= 12 12 kHz charging pulses Xx= 16 16 kHz charging pulses Yy= 00 1 pulse only at the moment of connection Yy= 01 to 99 seconds. Pulses each 01 up 99 seconds	0	0		
7	2	n				Amplification of sound in incoming direction (1 to 4)	1			
7	3	n				n= 0 CLIP is switch OFF n= 1 FSK CLIP Bell	1			
7	4	n				Call progress tone n=0 – OFF n=1 - ON	0			
7	5	n				Roaming n=0 – prohibited n=1 - permitted	1			
9	9					Default setting				

Table of tones

	<p>Dial tone (up setting) Mini Gate is ready to accept dial</p>
	<p>Busy tone – short tone repeated Called part is busy, doesnt exist, not permitted, etc..</p>
	<p>Ringing tone – long tone and pause repeated Called part is ringing</p>
	<p>Waiting tone – short tone repated with quick cadence. Mini Gate waiting for password insert</p>
	<p>Programming – short tone with quick cadence í Programming mode of Mini Gate</p>
	<p>Confirmation inquiry - 3 short tones Inquiry to confirm inserted parametr</p>
	<p>Confirmation tone – long tone Parametr was saved correctly.</p>
	<p>Minute tone – short tone with 1 minute period Minute beep to inform about GSM call.</p>
	<p>Call progress tone – short tones 3 s after sending number to GSM Searching of called part.</p>

LED signalling

		<p>Permanent light (lights up after power connection) Power supply of GSM unit</p>
		<p>Permanent light line OFF HOOK</p>
		<p>Doesnt light line ON HOOK</p>
		<p>Flashing in rythm of busy tone Programming or PC connection mode</p>
		<p>Flashing in rythm of busy tone Initialization mode after power supply connection, restart after programming etc..</p>
		<p>1- 5 flashes with period 4 sec. stand by mode. Number of flashes = signal strength</p>
		<p>Permanent light GSM connection is running (call)</p>
		<p>Short lights off with period 2 sec. GSM modul doesnt communicate to CPU</p>
		<p>Flashing in period 2sec SIM is not readed</p>
		<p>Short flashes in period 2 sec. Gate is not registrate to GSM network</p>


ACU pack installation

Backup battery 9.6 V/800mAh

1. Open Gateway cabinet



2. Remove cover of glue tape at bottom part of ACU pack



3. Fix the ACU pack into Gateway cabinet. CAUTION for holes for signalling LEDs! DO NOT COVER!



4. Rechargeable batteries may not be delivered in a charged state. Start the gateway first and wait for network log in. Then connect cable from ACU pack to appropriate connector..



5. Close the gateway cabinet and leave ACU charged up at least 2 hours without power supply disconnection.

Technical parametres:

Type	BlueGate A Brave UMTS
Operating position	various
Operating conditions	temperature: $-20^{\circ}\text{C} \div +40^{\circ}\text{C}$, humidity: $10\% \div 80\%$ at 30°C
Dimensions (mm)	100mm x 130mm x 37mm
Weight	

Part of power supply

Power supply	(adapter) 8-12VAC/DC, 1000mA
Protection	thermal fuse in adapter
Safety group	ČSN EN 60950 group 2

Analogue telephopne line

telephone interface	2-wires
telephone conector	RJ 11
Impedance	$600\ \Omega \pm 20\%$
Dial	tone DTMF $t_t > 30\ \text{ms}$ outgoing INBAND/OUTBAND
Billing	12/16 kHz
Start and end of connection	Polarity reversal

Supply conduction	24V
Current loop	max 29 mA
Resistance of subscribers conduction	max. $500\ \Omega$
Ringing	$55\ V_{\text{ef}} / 50\ \text{Hz}$
Signalization	$425\ \text{Hz} \pm 20\text{Hz}$

CLIP	FSK Bell
-------------	----------

GSM:

mobile network	Quad-Band 850/900/1800/1900Mhz and 2100MHz UMTS
provider	according SIM card (3V and 1.8 V)

USB:

built-in USB port	USB 2.0 full speed interface
option USB port	version 1.1, virtual COM

Functionality:

- Waiting for dial after pick up 1 - 99 sec or unlimited - If set 1, service Direct Call (Baby Call)
- Waiting for last digit of dial 1 - 15 sec
- Dial after preprogrammed number of digits 1 - 19
- Immediate dial sent up setting „#“ or „*“
- Permitted direction (9 memories of 4 digits numbers)
- CLIR
- CLIP
- Call billing (tax pulses 12/16 kHz)
- outgoing DTMF INBAND/OUTBAND
- Reversal polarity (start and end of call)
- Roaming ON / OFF
- Call duration control
- Time beeps in call
- GSM signal strength identification
- UMTS / HSDPA
- UMTS USB modem to connect one or more computers to the Internet network.
- Simultaneous voice and data connections in UMTS network



Alphatech Technologies s.r.o.
Jeremenkova 88
140 00 Praha 4
<http://www.alphatechtechnologies.cz>

25.7.2017